



Position	Code	Name
1	F0350302	TRIGGER GUARD ASSY WITH AUTO SAFETY 828U
1	F0354401	TRIGGER GUARD ASSY W/O AUTO SAFETY 828U
3	90015500	SCREW
4	G0636402	FIRE CONTROL HOUSING 828U
5	G0638200	STRIKER RETAINING CLIP 828U
6	G0638400	STRIKER SPRING 828U
7	G0636800	STRIKER 828U
8	G0638500	COCKING PLATE SPRING 828U
10	G0637801	SEAR SPRING 828U
11	F0365500	DISCONNECTOR ASSEMBLY 828U
12	G0637702	SEAR 828U
13	90002500	NEEDLE DIN 5402 NRB D. 2 X15,8
14	90033500	SEAR PIN 828U
15	G0637900	TOP SEAR CONNECTOR 828U
16	G0638100	CONNECTOR SPACER 828U
17	G0638000	BOTTOM SEAR CONNECTOR 828U
18	G0638300	CONNECTOR PIN 828U
19	G0636302	TRIGGER GUARD 828U
20	G0637402	SELECTOR INERTIA BLOCK 828U
21	F0354201	TRIGGER/SELECTOR ASSEMBLY 828U
22	G0627600	TRIGGER RETURN / EXTRACTOR SPRING 828U
23	90033000	TRIGGER PIN 828U
24	90032800	HOUSING RETAINING PIN 828U




Position	Code	Name
1	G0124000	CLIP BUTTON SPRING
4	G0630300	FIRING PIN 828U
5	G0630400	FIRING PIN SPRING 828U
6	90032400	FIRING PIN RET PIN 828U
7	G0630100	BREECH BLOCK BUSHING 828U
8	G0698302	BARREL LOCKING PIN D. 4.95 828U
9	G0899200	LH HINGE PIN 828U
11	90002500	NEEDLE DIN 5402 NRB D. 2 X15,8
12	G0899000	LH WEAR PLATE 828U
14	G0899100	RH WEAR PLATE 828U
16	G0899300	RH HINGE PIN 828U
18	G0644700	BUFFER 828U
19	F0349502	COCKING LEVER ASSEMBLY CHROMED 828U
21	90019300	TORX SCREW TX15 M4 X10
22	G0630602	BARREL LOCKING PLATE 828U
25	G0630801	LOCKING PLATE SPRING 828U
27	90032300	SAFETY SPRING SCREW 828U
28	G0628501	TRIGGER GUARD LATCH 828U
29	G0685900	TRIGGER GUARD SPRING 828U
30	G0628400	LATCH SPRING HOUSING 828U
31	G0632800	DROP SHIM 65 828U
31	G0632500	DROP SHIM 50 828U PIASTRINO VARIAZ. PIEGA 50 828U
31	G0632600	DROP SHIM 55 828U
31	G0632700	DROP SHIM 60 828U PIASTRINO VARIAZ. PIEGA 60 828U
31	G0632400	DROP SHIM 45 828U
33	G0632900	CAST SHIM 6MM 828U
33	G0633000	CAST SHIM 3 MM 828U
35	G0629700	STOCK BOLT 828U
36	G0187500	STOCK LOCKING PLATE, DROP 50/55 R.H./L.H. (STEEL)
37	90004800	ELASTIC WASHER

38	90006000	STOCK RETAINING NUT
39	G0629300	SAFETY RETAINER 828U
40	G0629201	SAFETY SPRING 828U
41	F0349201	SAFETY/SELECTOR ASSEMBLY BLUED 828U
42	G0631701	LEVER LOCK BUSH 828U
43	G0631600	LEVER LOCK PIN 828U
44	G0631101	BOLT HANDLE 828U (GLOSSY)
47	G0631500	LEVER LOCK SPRING 828U
48	G0631400	LEVER LOCK PLUNGER 828U



Position	Code	Name
4	F0348800	HUNTING LOW RIB ASSEMBLY 26" 828U
4	F0348900	HUNTING LOW RIB ASSEMBLY 28" 828U
4	F0349000	CARBON FIBER RIB 828U 30" HUNTING LOW
7	G0020900	FLUORESCENT FRONT SIGHT
8	G0627400	FIELD RIB SCREW 828U
9	F0107101	CRIO CHOKE FULL (*) 12GA
9	F0107201	CRIO CHOKE IM (**) 12GA
9	F0107301	CRIO CHOKE M (***) 12GA
9	F0107401	CRIO CHOKE IC (****) 12GA
9	F0107501	CRIO CHOKE CYL (*****) 12GA
13	F0353000	SLING SWIVEL BASE 828U
15	F0038501	SLING SWIVEL KIT
16	90032200	FORE-END ADJUSTING SCREW 828U
17	90015801	LOCK SCREW 828U
18	G0627500	EJECTOR SPRING 828U
19	G0627700	EJECTOR SPRING GUIDE 828U
20	G0064201	SAFETY POSITIONING PIN SPRING MP90S
21	90031800	SPRING RET PIN 828U
23	G0777800	PERNO ROTAZ. LEVA AGG. ESPUL 828U
25	F0417300	EJECTOR SEAR KIT 828U (*ONLY FOR AUTORIZED BENELLI SERVICE
27	G0627600	TRIGGER RETURN / EXTRACTOR SPRING 828U
28	G0627900	EJECTOR PISTON 828U
31	G0627800	EJECTOR SEAR DETENT 828U
32	90032100	EXTRACTOR RET PIN 828U
33	90020400	EXTRACTOR CASTER
34	90029300	CARTRIDGE DROP LEVER ROTATING PIN
35	G0628201	EXTRACTOR ROD 828U



Position	Code	Name
1	F0352900	POLYURETHANE RECOIL PAD KIT MED-MAX 828U
2	90031700	SCREW
3	F0348300	POLYURETHANE RECOIL PAD MED RAFF/ETH 365 + 828U 375
4	90031400	SELF-THREADED SCREW D 4.2X22
5	F0350000	PROGRESSIVE COMFORT HOUSING 828U
6	F0335000	COMB MEDIUM RAFFAELLO I3 / 828U
7	F0356800	STOCK ASSEMBLY, STANDARD 828U BLACK
7	F0388000	STOCK 828U BLK (X-GRAIN)
9	F0349800	STOCK ASSEMBLY, SHORT MEDIUM BLACK 828U
9	F0388200	ASS CALCIO L GR0 P/D VAR SM POL 365 X-GR VER 828U BLA
11	F0350700	WOODEN STOCK GR3 345MM OIL 828U BLACK
13	F0341600	COMB LOW RAFFAELLO I3 / 828U
14	90031300	SELF-THREADED SCREW D 3.5X13
15	F0329300	COMB BASE PLATE ASSEMBLY
18	G0028800	STOCK SLING SWIVEL SCREW, BLUED
19	F0038501	SLING SWIVEL KIT
20	F0350501	FORE-END IRON ASSEMBLY 828U
22	G0636701	VERTICAL FORE-END ADJUSTING SCREW 828U
23	G0633900	FORE-END SPRING CAP 828U
24	F0350400	FORE-END ADJUSTING SPRING 828U
25	G0634102	CROCE BRUN LUC. 828U
27	G0634001	FORE-END CATCH 828U
28	90010200	WASHER

29	90033800	FORE-END SCREW
30	G0731101	RUBBER FOREND INSERT 828SPT
31	G0632001	WOOD FORE-END 828U BLACK
31	G0714700	WOODEN FOREND 828U BLACK/BECCACCIA
33	G0133900	FIRING PIN SPRING M4
34	G0633401	FORE-END BUTTON 828U